


# XV Parts List



No.	Description	Qty	No.	Description	Qty	No.	Description	Qty
1	XV Oil stick		24	XV Crankshaft		47	O-ring	
2	XV Oil stick bushing		25	XV Left Side Cover		48	XV Main water seal bush	
3	O-ring		26	O-ring		49	O-ring	
4	Nut		27	XV Screw		50	Washer	
5	XV Rear cover		28	XV Plate		51	XV Mainfold	
6	O-ring		29	XV Bearing Bush		52	XV Plug G1/4	
7	XV Oil window		30	XV Connecting rod		53	XV Valve device	
8	XV Oil Level indicator		31	XV pin		54	Nut	
9	Washer		32	Washer		55	Washer	
10	O-ring		33	XV Plunger rod		56	O-ring	
11	XV Crankcase		34	Oil seal		57	XV Checking valve	
12	Bearing		35	XV Shim		58	XV Valve carriage	
13	XV Gasket		36	XV Ceramic plunger		59	XV Carriage washer	
14	XV Flange		37	XV Brass gasket		60	Washer	
15	Oil Seal		38	XV Screw		61	XV Discharge valve	
16	O-ring		39	O-ring		62	Washer	
17	XV Plate		40	Washer		63	XV Discharge valve ring	
18	Nut		41	XV Guide ring		64	XV Valve spring	
19	O-ring		42	XV Aux. water seal		65	Washer	
20	plug G1/2		43	XV Support ring		66	XV Valve plug	
21	XV Lift		44	XV Flat gasket		67	XV Valve cover	

22	Nut		45	XV Main water seal		68	Nut	
23	XV Plate		46	XV Gasket				